



### To Stroke Reduce

1. Remove RAMP tube with 34mm Crow's foot Wrench
2. Slide Bottom out washer and O-ring down toward seal head
3. Click Stroke Reducer onto shaft, and align with slot in valve body
4. Grease seals/O-rings and Tighten Ramp Tuber to 14.5Nm

