




INF-2 Shop Inflator

Park Tool Co. 5115 Hadley Ave. N., St. Paul, MN 55128 (USA) www.parktool.com



INF-2 Part Numbers

Part No.	Description	Qty.
1	1571.2 Body	1
2	1572.2 Coupler Plug	1
3	1573.2 Trigger	1
4	1574-2 Handle Spacer	2
5	1575 Valve Poppet	1
6	1577 Bleed Valve Poppet	1
7	1579 Bleed Valve Body	1
8	1580 Bleed Valve Button	1
9	1581 Gauge Ring	1
10	1064 Pressure Gauge	1
11	1583 Retaining Ring	1
12	1584 Head Adaptor	1
13	1585.2 Presta Cap	1
14	1586 Presta Seal	1
15	1587.2 Head	1
16	1588 Schrader Seal	1

Part No.	Description	Qty.
17	1590A Shuttle Valve Assembly	1
18	1591.2 Schrader Cap	1
19	1017 Plunger Spring	1
20	1594 Skewer Spring	1
21	1578-2 Button Head Socket Cap Screw	2
22	1595 O-Ring AS568-104	1
23	1628-2 O-Ring AS568-010	2
24	1625-2 O-Ring AS568-007	1
25	1624-2 O-Ring AS568-006	1
26	1593 Plain Washer	1
27	1592 O-Ring AS568-110	1
28	1576-2 Metric O-Ring	2
29	1626-2 O-Ring AS568-008	1
30	1581B Gauge Boot	1
31	1587.2A Head Assembly	—

1590A Shuttle Valve Assembly includes (2) 1576-2 & 1588