

Part Number	Description	Part Included
F60061	AXLE,VAULT,REAR,421,SILVER	E
F60078	BEARING,6902 CM	D
F60063	ENDCAP SET,VAULT,R,12X142	B,L,P,S
F60066	ENDCAP SET,VAULT,REAR,12X135	A,K,O
F60069	ENDCAP SET,VAULT,REAR,421,10X135QR	C,M,Q
F60072	SEAL,VAULT,CASSETTE BODY,BLACK	I
F60074	PAWL AND SPRING KIT,VAULT	GX6, HX6
D60073	SPACER VAULT CASSETTE BODY SILVER	F
F60076	CASS BODY,VAULT,SHI MTN 9/10/11SPD, 60T	F,J,L
F60077	CASS BODY,VAULT,XD,60T	F,N,P
F60144	CASS BODY,VAULT,MICRO SPLINE SHI12,60T	F,R,S
D60185	BEARING,DRIFT,KIT,VAULT,F+R	NOT SHOWN

### NOTES

1. See raceface.com for service and repair instructional videos
2. Remove end caps by hand, if tight try using a rubber glove or blind bearing puller tool
3. Always install drive side bearing first
4. Longer end cap install on rotor side
5. See raceface.com for list of recommended lubricants
6. Lube with light grease:
  - i. Outside facing bearing seals
  - ii. OD bearing race where end cap seal contacts
  - iii. Drive ring
7. Lube with light oil:
  - i. Pawls
  - ii. Cassette body seal
8. Lube with waterproof grease:
  - i. Cassette / cassette body stop interface
  - ii. Outside face of outer bearing for XD and Micro Spline cassette bodies

