

Part Number	Description	Part Included
F60062	AXLE,VAULT,REAR,424,BOOST,BLACK	C
F60078	BEARING,6902 CM	B
F60063	ENDCAP SET,VAULT,R,12x148	A,I,K,M
F60072	SEAL,VAULT,CASSETTE BODY,BLACK	G
F60074	PAWL AND SPRING KIT,VAULT	E x 6, F x 6
D60073	SPACER VAULT CASSETTE BODY SILVER AM	D
F60076	CASS BODY VAULT SHI MTN, 9/10/11SPD, 60T AM	D,H,I
F60077	CASS BODY,VAULT,SRAM,XD,60T	D,J,K
F60144	CASS BODY,VAULT,MICRO SPLINE SHI12,60T	D,L,M
D60185	BEARING,DRIFT,KIT,VAULT,F+R	NOT SHOWN

NOTES

1. See raceface.com for service and repair instructional videos
2. Remove end caps by hand, if tight try using a rubber glove or blind bearing puller tool
3. Always install drive side bearing first
4. Longer end cap install on rotor side
5. See raceface.com for list of recommended lubricants
6. Lube with light grease:
 - i. Outside facing bearing seals
 - ii. OD bearing race where end cap seal contacts
 - iii. Drive ring
7. Lube with light oil:
 - i. Pawls
 - ii. Cassette body seal
8. Lube with waterproof grease:
 - i. Cassette / cassette body stop interface
 - ii. Outside face of outer bearing for XD and Micro Spline cassette bodies

