

Getting Started



Congratulations on your new Juno 100 Road!

Inside the box contains three items:

- Juno 100 Road
- Silicone Mounting Band
- USB Charging Cable

Charging the Battery



Charge the Juno 100 Road using the USB charging cable provided. A red light will appear next to the ON button indicating charging.

When a green light appears the Juno 100 Road is fully charged.

Light Modes and Operation

There are six light modes available:

- Flash Low
- Flash High
- Super Flash
- Steady Low
- Steady Medium
- Steady High

The six light modes are set within two cycles:

Cycle 1	Cycle 2
---------	---------

Flash Low	Steady Low
Flash High	Steady Medium
Super Flash	Steady High

Press the ON button to turn on the Juno 100 Road. The light will begin in Cycle 1.

With each press and click of the button, the Juno 100 Road will switch to the next light mode:

Flash Low → Flash High → Super Flash

With a double click of the button, the Juno 100 Road will switch to the other mode Cycle:

Cycle 1 → Cycle 2 (Steady Low, Steady Medium, Steady High)

To turn OFF the Juno 100 Road, press and hold the button for 2 seconds.

Did this answer your question? 😊 ☹️

✉ Still need help? [Contact Us \(/contact\)](/contact)

Last updated on June 22, 2020

© Gemini Lights (<https://gemini-lights.com>) 2020. Powered by Help Scout
([https://www.helpscout.com/knowledge-base/?
utm_source=docs&utm_medium=footerlink&utm_campaign=Docs+Branding](https://www.helpscout.com/knowledge-base/?utm_source=docs&utm_medium=footerlink&utm_campaign=Docs+Branding))